


AquaCal[®] Operation Manual

TropiCool[™] WATER CHILLER



Important

Read this document before operating / installing this product

For additional product manuals and operation / installation procedures, please visit www.AquaCal.com

MODEL / SERIAL NUMBER

Table of Contents

Section 1 - Contacting AquaCal AutoPilot, Inc.

Section 2 - Safety

Section 3 - Operation

3.1 Energizing Chiller	2
3.2 Display Lock	2
3.3 Control Panel	2
3.4 Buttons	2
3.5 Indicator Lights	2
3.6 Display	3
3.7 Factory Defaults	3
3.8 Setting Operating Mode	4
3.9 Setting Thermostats	4
3.10 Selecting Celsius or Fahrenheit	5
3.11 User Lock Option (Enable)	5
3.12 User Lock Option (Entering Pass Code)	5
3.13 User Lock Option (Disable)	6

Section 4 - Maintenance

4.1 Monitoring Conditions	6
4.1.a Water Chemistry	6
4.1.b Water Flow Rates	7
4.1.c Irrigation and Storm Run-Off	8
4.1.d Clearances	8
4.2 Cleaning Equipment	9
4.3 Planned Maintenance	10
4.4 Winterizing	10

Section 5 - Troubleshooting

5.1 Fault Codes	12
5.2 Issues and Resolutions	14

Section 6 - Appendix

6.1 Identifying Model Specifications	17
6.2 Initial Cooling Recommendations	18
6.3 Available Accessories	18

SECTION 1 - CONTACTING AQUACAL AUTOPILOT, INC.

For further assistance, please contact the installing dealer or contact AquaCal AutoPilot, Inc. for a service partner in your area. To better assist you, please have the chiller model and serial number available. See "Identifying Model Specifications" on page 17.



Website	www.AquaCal.com
Request Service Online	www.AquaCal.com/request-heat-pump-service/
Phone	(1) 727-823-5642
Hours	8-5 pm, Eastern M-F

SECTION 2 - SAFETY



- For personal safety, and to avoid damage to equipment, follow all safety instructions displayed on the equipment and within this manual. Repair and service of chiller must be performed by an authorized service center.
- Warranties may be voided if the equipment has been improperly installed, maintained or serviced.
- If service is deemed necessary, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

SAFETY SIGNALS

Throughout this document, safety signals have been placed where particular attention is required.

-  **WARNING** - signals relate to personal safety.
-  **CAUTION** - signals promote avoiding damage to the equipment.

When installing and using your chiller basic safety precautions must always be followed, including the following:

-  **WARNING** - Failure to heed the following may result in injury or death.
 - Installation and repairs must be performed by a qualified technician.
 - The chiller contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained and / or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.
 - The chiller utilizes high voltage and rotating equipment. Use caution when servicing.
 - Electrical installation and service should be performed by a Licensed Electrician only.
 - Improper water chemistry can present a serious health hazard. To avoid possible hazards, maintain pool / spa water per standards detailed in this document.
 - Prolonged immersion in water colder than normal body temperature may cause a condition known as Hypothermia. The symptoms of Hypothermia include shivering (although as hypothermia worsens, shivering stops), clumsiness or lack of coordination, slurred speech or mumbling, confusion and poor decision-making, drowsiness or low energy, lack of concern about personal welfare, progressive loss of consciousness, weak pulse and slow or shallow breathing. In addition, persons having an adverse medical history, or pregnant women, should consult a physician before immersing in a cold body of water. Children and the extreme elderly should be supervised by a responsible adult.
-  **CAUTION** - Failure to heed the following may result in equipment damage.
 - Maintain proper water chemistry in order to avoid damage to pump, filter, pool shell, etc.
 - Water flow exceeding maximum flow rate requires a bypass. Damage due to excessive water flow will void warranty.

SAVE THESE INSTRUCTIONS

SECTION 3 - OPERATION

3.1 Energizing Chiller


Turn power on at external fuse box or breaker disconnect.

- Controller performs a lamp test.
- The display reads **BBB**.
- Controller then displays as normal. See "Display" on page 3.

3.2 Display Lock

The chiller has a display lock to protect against inadvertent setting changes. To activate display and controls, slide finger across the controls as shown from left to right.


- The code **UnL** will briefly appear, then the set temperature or mode will display.
- This is different than a user-lock which requires a pass code. See "User Lock Option (Enable)" on page 5.



3.3 Control Panel

The following information outlines the operation for a standard installation.

Control Panel



3.4 Buttons

Buttons	Description
Display Lock	Sliding your finger across the buttons from left to right will temporarily disable the display lock.
Pool / Spa	Select either the pool or the spa thermostat.
Up Arrow	Used to increase temperature set point and navigate through menu options.
Down Arrow	Used to decrease temperature set point and navigate through menu options.
Mode	Select chiller's operating mode.

3.5 Indicator Lights

Indicators	Description
Pool	The Chiller is referencing the pool thermostat.
Spa	The Chiller is referencing the spa thermostat.
Cooling	Indicates the unit is cooling the water. Please note - the compressor must be operating before this light will illuminate.
Water Temp	Indicates current water temperature.
Desired Temp	Indicates temperature set point is displayed. This is displayed when "UP" or "DOWN" is selected.

3.6 Display

Display	Description
75	The chiller is on and displaying the current water temperature. In this example 75° F is displayed.
FLO	No water flow is detected. The filter pump is off or chiller is not receiving correct water flow.
OFF	The chiller has been turned off via the mode selector button or the temperature set point has been lowered below 45° F.
BBB	The control program is initializing. This displays only as power is applied to the chiller. The program version number will then be displayed.
CF 1	Select water temperature format (in either Celsius or Fahrenheit).
ULC	Enable chiller lockout feature.
ELC	Select passcode to lock the keyboard.
LDC	This is a Service Entry Point (not intended for use by the owner). The LDC code permits service personnel to enter a factory passcode to access adjustable calibration and site dependent setup parameters. Service adjustments are available to authorized installation and service personnel, only.

3.7 Factory Defaults

Certain programming options have been preset at the factory. These options can be overwritten for site-specific conditions.

 CAUTION - Failure to heed the following may result in equipment damage.

- Service Level Programming must only be attempted by authorized service centers.
- Unauthorized adjustments in the Service Menu (beyond the LDC menu) may void chiller's warranty.
- If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

Table 1 - Factory Defaults

CODE	DESCRIPTION	DEFAULT VALUE	RANGE
OFF	Chiller is deactivated.	OFF	
HEA	This is not an active feature on this equipment.		
COO	Set to cool water to point set on thermostat.		
ACH	This is not an		


CODE	DESCRIPTION	DEFAULT VALUE	RANGE
	active feature on this equipment.		
<i>CF 1</i>	Celsius / Fahrenheit Selection	1	0 = Celsius 1 = Fahrenheit
<i>ELC</i>	Enter Lock Code	0	0 - 99
<i>ULE</i>	User Lock Code	0	0 = "User Lock Disabled" 1 = "User Lock Enabled"

3.8 Setting Operating Mode

PLEASE NOTE

Do not attempt to operate chiller in heat modes *HEA* or *RCH*. This is not an active feature on this equipment.

Cool Mode




Deactivate Chiller




Heating / Cooling modes only available on select equipment. Confirm chiller features before setting a mode.


3.9 Setting Thermostats



Select "POOL" or "SPA"




Press "UP" or "DOWN" to the desired temperature.




- The cooling indicator will illuminate when cooling the water.

3.10 Selecting Celsius or Fahrenheit



Hold "UP" and "DOWN" until **CF** displays.



"0" - Celsius
"1" - Fahrenheit


3.11 User Lock Option (Enable)

The user-lock feature allows the chiller control panel to be "locked"; preventing unauthorized temperature adjustments.

- Do not confuse a user-lock with the display lock. See "Display Lock" on page 2.
- If **LOC** is briefly displayed, followed by a "0", the chiller is already locked.



Hold "UP" and "DOWN" until **CF** displays.




Press "POOL / SPA" button until **ELC** is displayed.




Press "UP or "DOWN" button to change or add a numerical password



Press "POOL / SPA" button to lock in the password.




Press "POOL / SPA" button until **ULC** is displayed.



Press "Up" button till "1" is displayed to enable.

3.12 User Lock Option (Entering Pass Code)

If **LOC** is briefly displayed when attempting to change a chiller's settings followed by a "0", the chiller is in a user-lock mode. A numerical passcode is required to proceed.



Press "UP" or "DOWN" arrow to enter user lock code.




Press "POOL / SPA" button again to unlock.


NOTE -

- After three seconds of inactivity, the chiller's slide lock will activate.
- If the user-lock code has been misplaced, the chiller must be reset to default factory settings. See "Reset to Factory Defaults Settings" on page 1.


3.13 User Lock Option (Disable)



Use "UP" button to enter existing password.




Press "Pool / Spa" button to unlock.



Hold "UP" and "DOWN" buttons until CFI is displayed.



Press "POOL / SPA" button until ULC is displayed



Press "DOWN" button until "0" is displayed.

SECTION 4 - MAINTENANCE

4.1 Monitoring Conditions

4.1.a Water Chemistry

Check water chemistry regularly and maintain within recommended levels. Standards for commercial applications vary in different areas. Follow all local applicable codes.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Do not allow water to flow through chiller when refinishing or acid washing a pool. Either use an installed bypass to route water away from chiller or deactivate filter pump.
- To avoid damage to equipment, monitor and maintain chemistry within recommended levels.

CHEMISTRY LEVEL CHART (RESIDENTIAL)		
CHEMICAL	POOLS	SPAS
Chlorine	1.0 – 3.0 ppm	3.0 – 5.0 ppm
Bromine	2.0 – 6.0 ppm	2.0 – 6.0 ppm
Cyanuric Acid	30 - 50 ppm	30 - 50 ppm
pH	7.4 – 7.6 ppm	7.4 – 7.6 ppm
Total Alkalinity	80 – 120 ppm	80 – 120 ppm
Calcium Hardness	200 – 400 ppm	150 – 250 ppm
Total Dissolved Solids*	0 – 1,500 ppm	1,500 ppm above start-up total dissolved solids in spas

* Salt from a chlorine generator is not included in Total Dissolved Solids.

4.1.b Water Flow Rates

Maintain water flow rates as indicated. Please note, these specifications relate to the chiller only. Code-specified whole system turnover rates must be satisfied.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Water flow exceeding maximum flow rate may damage heat exchanger; such damage will not be covered under the equipment warranty

MODEL	HEAT EXCHANGER TYPE	FLOW RATES	
		MINIMUM	MAXIMUM
TC500	Titanium Tube-in-Tube	20 GPM	45 GPM
TC1000	Titanium ThermoLink®	30 GPM	70 GPM

If water flow through the chiller is reduced, performance will suffer and internal safety devices may deactivate the chiller with error codes **LP** or **LPS**.

- Operate water filtration devices per manufacturer's specifications. Dirty filters can cause reduced water flow to the chiller. An increase of 7-10 psi higher than the clean filter pressure typically reduces flow rates. This requires the filter to be cleaned or back-washed
- Keep baskets free of debris. Similar to a dirty filter, large volumes of debris in the pump and skimmer baskets can reduce water flow.
- Check for improper valve settings. A partially closed valve after the filter, or a full-open bypass around the chiller, will cause insufficient water flow through the chiller.

- The maximum static (or operating pressure) is 50 pounds-per-square-inch (PSI) unless a special "high-pressure" unit has been ordered. These specifications relate to the chiller only. Code-specified whole system turnover rates must be satisfied.


4.1.c Irrigation and Storm Run-Off

- Corrosive irrigation water may damage chiller components. Have irrigation water directed away from the chiller.
- The chiller will withstand normal rainfall. Do not allow a roof slope to direct rainwater onto the chiller. Have a gutter installed on the roof edge to direct this water away from the chiller. Or install the chiller in another location.


4.1.d Clearances

- Proper air circulation is required for the chiller to operate efficiently. Avoid placing objects near or on top of the chiller. This includes shrubbery and lawn furniture. These objects will also hinder maintenance access.
- Avoid storing chemical containers near the heat pump. The chemicals can cause equipment damage.

Overhead Clearance (not including SideWinder™)



TropiCool™ (Top View)



4.2 Cleaning Equipment

Cleaning and polishing your chiller regularly can protect its appearance longevity. More frequent servicing may be required for chillers located in sandy or coastal areas where sand and salt spray can become detrimental factors to equipment.

⚠ WARNING - Failure to heed the following may result in injury or death.

- Possible electric shock hazard - Deactivate power to all electrical devices on the pad when washing chiller. Do not restore electrical power until equipment is completely dry.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Do not use a pressure cleaner to wash chiller. Damage to chiller components may result. If using a hose-end spray nozzle adjust spray pattern to low strength only.
- Do not spray water directly into the interior of the chiller; damage to components may result.
- Do not use chemicals on the control panel.

Cleaning

1. Wash outside cabinet using a low-pressure water hose. A high-pressure water stream will cause damage to the aluminum fins of the chiller. This damage is not covered under product warranty.
2. While the chiller is still wet, use an approved cleaning agent to clean the exterior of the chiller. **Do not use chemicals on the control panel.**
3. Use a detergent-dampened cloth to wipe the chiller's exterior cabinet.
4. Flush all exterior with fresh water using a low-pressure water hose.
5. Dry the exterior cabinet using a soft cloth being careful not to damage condenser fins.

APPROVED CLEANING AGENTS*
Fantastic [®]
Formula 409 [®]
Cascade [®]
All Power Plain Detergent (3% Solution)

Table 2 - Cleaning Agents

Polishing

1. Polish the chiller's cabinet panels using an approved polishing agent and following the manufacturer's instructions. Do not use chemicals on the control panel.
2. Rinse the chiller panels with fresh water, wipe, and buff panels using a dry soft cloth.
3. Allow chiller interior and surrounding equipment to "air-dry" for several hours prior to restoring electrical power.

APPROVED POLISHING AGENTS*
Simoniz [®] Wax
AeroWax [®]
Glo-Coat [®]
Armor All [®] Protectant

Table 3 - Polishing Agents

- * The trademarks used in approved cleaning and polishing agents are property of their owners and are not related to AquaCal[®].

4.3 Planned Maintenance

An annual inspection and maintenance program is strongly recommended starting no longer than one year after installation of the chiller. See recommended annual inspection checklist.

AquaCal® can perform this service in limited areas. Contact Customer Support for more information.

⚠ WARNING - Failure to heed the following may result in injury or death.

- Annual inspection and service must be performed by a qualified chiller specialist in order to prevent physical injury or damage to equipment.

RECOMMENDED INSPECTION CHECKLIST:

- Check Air Temperature Change through Evaporator
- Check and Clean Condensate Drains
- Check Capacitor Value
- Check Compressor Amperage Draw
- Check Electrical Connections
- Check Flow / Pressure Switch
- Check Operating Controls and Temperature Sensors
- Check Water Chemistry
- Check Proper Voltage to Unit
- Check Refrigerant Levels
- Check Relay Contacts
- Check Water Flow
- Check filter pump Amperage Draw
- Check Water Temperature Change through Heat Exchanger
- Clean Condenser's Coil
- Clean Chiller's Cabinet

4.4 Winterizing

⚠ WARNING - Failure to heed the following may result in injury or death.

- Deactivate all electrical power to chiller before performing hard freeze procedures.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Failure to winterize chiller may result in serious equipment damage. Freeze damage is not covered under the chiller warranty.
- While the plumbing connections are in the winterized condition (not fully tightened), it is imperative the pool and spa water not be circulated through the chiller. Loss of water through loose plumbing connections may result in damage to circulating pump, pool and spa structures, and other equipment.

Light Freeze Conditions

There are two freeze conditions requiring chiller attention. A light freeze is when the ambient air temperature falls below 32 degrees Fahrenheit for less than 8 hours. Typically during light freeze conditions circulating (moving) water will not freeze. Override time clocks and allow filtration system to run continuously during light freeze conditions.

Hard Freeze Conditions

A hard freeze is when the ambient air temperature falls below 32 degrees Fahrenheit for more than 8 hours. In areas where this condition is prevalent and sustained, the chiller **MUST** be winterized for hard freeze conditions. Follow the correct procedure depending on the type of heat exchanger found in the chiller.

Identify Exchanger:

1. Deactivate all electrical power to chiller.
2. Deactivate filter pump.
3. Remove front access panel.
4. Identify chiller exchanger from illustrations in this section. Then follow procedure for that chiller's exchanger.

Titanium ThermoLink® Exchanger (with no Drain)

1. Reinstall front access panel.
2. Disconnect the plumbing to the chiller at connection unions (removal is counter-clockwise).
3. Allow water to drain completely from the chiller. Expect to see a lot of water drain out at first, and then a small amount to continue to drain out over a long period.
4. After chiller is fully drained, reinstall front access panel.
5. Partially reconnect plumbing connection unions.
6. Winterizing is complete.
7. When ready to use chiller again, hand-tighten connection unions. Reconnect electrical power, and set the operating mode on the chiller. Activate filter pump.


No Drain



Cupronickel Tube in Tube Exchanger

1. Reinstall front access panel.
2. Disconnect the plumbing to the chiller at connection unions (removal is counter-clockwise).
3. Place a garden hose into the inlet side of the chiller; wrap a clean rag around the hose to form a temporary seal.
4. Turn on the garden hose water supply.
5. Allow water to run through the heat exchanger for 2-3 minutes; fresh water should be seen exiting the pool's out-port.
6. Place a garden hose into the outlet side inlet of the chiller; wrap a clean rag around the hose to form a temporary seal.
7. Turn on the garden hose water supply.
8. Allow water to run through the heat exchanger for 2-3 minutes; fresh water should be seen exiting the pool's in-port.
9. Place an air hose into the pool inlet of the chiller; wrap a clean rag around the hose to form a temporary seal.
10. Push all water from the water circuit using compressed air at approximately 50 psig. The residual water should be forced out of the chiller pool outlet.
11. Allow compressed air to blow into the chiller inlet for at least 15-20 seconds after the water stops coming out.
12. Repeat process on the outlet side.
13. Partially reconnect plumbing connection unions.
14. Winterizing is complete.
15. When ready to use chiller again, hand-tighten connection unions. Reconnect electrical power, and set the operating mode on the chiller. Activate filter pump.


**Cupronickel
(Orientation
depends
on model)**



Titanium Tube-in-Tube Exchanger

1. Disconnect the plumbing to the chiller at connection unions (removal is counter-clockwise).
2. Allow water to drain completely from the chiller. Expect to see a lot of water drain out at first, and then a small amount to continue to drain out over a long period.
3. Place an air hose into the pool inlet of the chiller; wrap a clean rag around the hose to form a temporary seal.
4. Push all water from the water circuit using compressed air no stronger than 50 psig. The residual water should be forced out of the pool outlet. Allow compressed air to blow into the chiller inlet for at least 15-20 seconds after the water stops coming out.
5. Repeat process on the outlet side of the chiller.
6. Partially reconnect plumbing connection unions.
7. Winterizing is complete.
8. When ready to use chiller again, hand-tighten connection unions. Reconnect electrical power, and set the operating mode on the chiller. Activate filter pump.

**Titanium
Tube-in-
Tube**



SECTION 5 - TROUBLESHOOTING

5.1 Fault Codes

A fault code indicates a specific issue or condition that will require action before the equipment can resume operating.

Please perform the following troubleshooting.

If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

⚠ WARNING - Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The chiller contains refrigerant under high pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Service by unauthorized personnel will void the chiller warranty.

FLD Indicator

ISSUE

Low or no water detected.

RESOLUTION

1. Confirm the filter pump is on.
2. If a multiple-speed filter pump is being used, run at a higher speed to determine if the error persists. Do not exceed maximum flow rate for your model.
3. Confirm water is not being diverted away from the chiller.
 - See "Water Flow Rates" on page 7.
 - See "Adjusting Water Flow Using ΔT (Delta-T)" for more information.

CEr Indicator

ISSUE

This can indicate a loose or damaged communication cable.

RESOLUTION

A qualified technician should check the cable from control board to display assembly for a loose connection or visible damage.

CSE Indicator

ISSUE

This is a control system error.

RESOLUTION

1. Deactivate then reactivate power to reset controls.
2. If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

dPC or dPD Indicator

ISSUE

Shorted or open defrost sensor.

RESOLUTION

A qualified technician should replace the defrost sensor.

PC or PD Indicator

ISSUE

Shorted or open water sensor.

RESOLUTION

A qualified technician should replace the defrost sensor.

HP Indicator

ISSUE

The refrigerant system's high-pressure switch is showing as open.

RESOLUTION

1. Determine if an insufficient amount of water is being supplied to the equipment.
 - a. Confirm the filter pump is on.
 - b. If a multiple-speed filter pump is being used, run filter pump at a higher speed. Do not exceed maximum flow rate for your model.
 - c. Confirm water is not being diverted away from the chiller.
 - See "Water Flow Rates" on page 7.
 - See "Adjusting Water Flow Using ΔT (Delta-T)" for more information.
2. If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

HP5 Indicator

ISSUE

The chiller has locked due to five **HP** (high-pressure) faults during one call for heating or cooling.

RESOLUTION

1. Deactivate then reactivate power to the chiller to clear error.
2. Troubleshoot the high-pressure issue causing the error. See "HP Indicator" on page 13.
3. If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

LP Indicator

ISSUE

The refrigerant system's low-pressure switch is showing as open.

RESOLUTION

1. Check for obstructed air flow around the heater. See "Clearances" on page 8.
2. Check for dirty or blocked evaporator coil. See "Cleaning Equipment" on page 9.
3. Check for signs of ice buildup on the coil.
4. For further assistance, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

LP5 Indicator

ISSUE

The chiller has locked due to five **LP** (low-pressure) faults during one call for heating or cooling.

RESOLUTION

1. Deactivate then reactivate power to the chiller to clear error.
2. Troubleshoot the low-pressure issue causing the error. See "LP Indicator" on page 14.

OWA Indicator

ISSUE

Incoming water temperature exceeded 110° F and the unit is locked with an **OWA** over temperature alarm. The chiller will not operate until incoming water temperature drops to 100° F or lower.

RESOLUTION

1. Rule out an incorrect reading from the water temperature sensor. Verify existing water temperature with an accurate thermometer. If chiller's sensor is inaccurate, the water temperature sensor may require replacement.

5.2 Issues and Resolutions

⚠ WARNING - Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The chiller contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

⚠ CAUTION - Failure to heed the following may result in equipment damage.

- Service by unauthorized personnel will void the factory warranty.

Please perform the following troubleshooting.

For further assistance, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

Control Panel Not Responding

1. If the chiller is controlled by an external controller, confirm the external controller settings. See "Operating Chiller (With an External Controller)" on page 1.
2. If the issue is still occurring, contact the manufacturer of the external control device.
3. For further assistance, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

Chillers Not Running

1. Confirm equipment is receiving power. Is the chiller display illuminated?
 - If not, confirm the main breaker (located at the power supply panel) and the disconnect switch (located near the chiller) are both turned on.
 - If the display still does not illuminate, it is recommended that the chiller installer or electrician confirms chiller is receiving power.
2. Confirm correct mode is selected. See "Setting Operating Mode" on page 4.
3. Confirm thermostat is set correctly. See "Setting Thermostats" on page 4.
 - If cooling the water, the thermostat should be set below the current water temperature.
4. If an error code is displayed, diagnose and correct the cause of the code. See "Fault Codes" on page 12.
5. For further assistance, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

Chillers Tripping Breaker

1. Have an electrician confirm breakers are in good condition and properly sized for the chiller.
2. Multiple chillers installed at the same site may benefit from special automatic sequencing controllers to avoid excessive power drops at start-up. See "Automatic Sequencing Controller" on page 18.
3. If a fault occurs immediately when the compressor starts, a qualified technician should evaluate the system.

Chiller Won't Shut Off

1. If the chiller is incorrectly set to *HEA* or *ACH* mode, the unit will not deactivate. See "Setting Operating Mode" on page 4.

Chiller Is Running, Not Cooling (Reversing Models)

1. Confirm the chiller mode is set to *CDD* operating mode.
2. Confirm the thermostat is set below the current water temperature.
3. Confirm chiller is transferring heat out of the water.
 - Measure the temperature of air discharge coming out of chiller fan. If discharge air is between 8° to 10° warmer than outside ambient air (not coming out of chiller), then the chiller is moving heat out of the water.
4. If an error code is displayed, determine and correct the condition causing the code. See "Fault Codes" on page 12.
5. Confirm valves are correctly positioned to cool the correct body of water (either the pool or the spa). If cooling a spa that overflows into a pool, confirm the spa is isolated when being cooled (not flowing into the pool).
6. Confirm that filter pump has a sufficient run-time. The chiller will not run (or cool the water) without water flow. See "Initial Cooling Recommendations" on page 18.

Water Coming From Chiller

The water may be normal condensation produced as a by-product of the chiller's refrigeration process. The chiller can produce 8 to 10 gallons of condensation per day depending on the humidity of the ambient air.

Determine if the water is condensation or a possible leak.

1. If using chlorine or bromine as a pool / spa sanitizer, use a test strip in the water at chiller to determine if sanitizer is present. If sanitizer is present, a leak may exist.
2. Deactivate chiller, leaving the filter pump on. After several hours, determine if water is still coming from the chiller.
3. If the issue reoccurs, please contact the installing dealer. Or contact AquaCal® for a service partner in your area. See "Contacting AquaCal AutoPilot, Inc." on page 1.

SECTION 6 - APPENDIX


6.1 Identifying Model Specifications

1. Find Data Plate - The data plate is usually posted on the side of the equipment or on the control panel access plate.
2. Find the model number on the data plate. The first letters and numbers indicate the model type.
3. The complete model number identifies the equipment's specifications.

Data Plate Example

MINIMUM CIRCUIT AMPACITY	<input type="text"/>	MADE IN THE USA
ELEC. SERVICE: VOLTS	<input type="text"/>	PH <input type="text"/> HZ <input type="text"/>
MAXIMUM TIME DELAY FUSE OR HACR BREAKER		<input type="text"/> 5
COMPRESSOR VOLTS	R.L.A. <input type="text"/>	L.R.A. <input type="text"/>
FAN MOTOR VOLTS	H.P. <input type="text"/>	F.L.A. <input type="text"/>
REFRIGERANT: Circuit - Factory charged		<input type="text"/> Only oz/Kg <input type="text"/>
Tested to <input type="text"/> psig High side / <input type="text"/> psig Low side		
AQUA CAL, INC A TEAM HORNER COMPANY 2737 24 TH STREET NORTH ST. PETERSBURG, FL 33713 FACTORY SERVICE 727-523-5642		MODEL NUMBER <input type="text"/> IIIBAR CODEIII SERIAL NUMBER <input type="text"/> IIIBAR CODEIII

Model Number Example



6.2 Initial Cooling Recommendations

The following recommendations will reduce the amount of time required to cool a pool or cold plunge application. **If unsure of equipment cooling capability, review equipment data plate.** See "Identifying Model Specifications" on page 17.

1. Confirm chiller mode has been set to **COO**.
2. Set thermostat to desired water temperature.
3. Temporarily override the filter pump's time-clock for continuous operation.
 - This will allow the Chiller the time required to cool the water at start-up.
 - After the water has reached the desired temperature, the time-clock can be reset to normal operating time-frames.

6.3 Available Accessories

Automatic Sequencing Controller

- An Automatic Sequencing Controller (ASC) provides easy control of all units from one lead unit and prevents the simultaneous start-up of multiple chillers.
- Site voltage drop is minimized and utilities are not subjected to large in-rush demands of electrical current.
- Part number is based on number of chiller's to be controlled. Call AquaCal® Customer Support for assistance with correct configuration.

5 lb Bypass Valve Kit (Kit STK0135)

- When high flow rates are outside recommended tolerances, please use this kit or an alternative bypass valve system.
- This kit can be used to control excessive water flow through the chiller. It provides automatic flow adjustments for most applications.

External Flow Relay (Grid Flow) Switch Kit (0040s)

- Used when the pool / spa elevation is higher than the chiller.
- Used when a variable two-speed filter pump set on low-speed mode does not provide enough water pressure to activate a chiller's water pressure switch.
- Also used for automatic pool / spa thermostat switching.

Remote Control Kit (STK0070)

- A remote (wired) control kit allows for full control of the chiller from up to 100 feet from the equipment.

Plumbing Unions:

SIZE	PART NUMBER
2 INCH	2627