

# AquaCal® Installation Manual


**TropiCool**  
WATER CHILLER



## Important

Read this document before operating / installing this product

For additional product manuals and operation / installation procedures, please visit [www.AquaCal.com](http://www.AquaCal.com)



MODEL

/

SERIAL NUMBER



# Table of Contents

---

<b>Contacting AquaCal AutoPilot, Inc.</b> .....	<b>1</b>
<b>Safety Instructions</b> .....	<b>1</b>
<b>1 - Installation</b> .....	<b>3</b>
1.1 Dimensions .....	3
1.2 Positioning Equipment .....	3
1.3 Clearances .....	5
1.4 Plumbing .....	5
1.4.a Plumbing Requirements .....	5
1.4.b Plumbing Diagrams .....	6
1.4.c Plumbing Diagrams .....	9
1.4.d Water Connections to Chiller .....	10
1.4.e In-Line Chlorine Feeders .....	11
1.4.f Water Flow Rates .....	11
1.4.g Maintaining Ability to Winterize .....	12
1.4.h Adjusting Water Pressure Switch .....	12
1.5 Electrical .....	13
1.5.a Electrical Requirements .....	13
1.5.b Incoming Power Access Holes .....	15
1.5.c Access Panels .....	16
1.5.d Verifying Transformer Setting .....	16
1.5.e Three-Phase Adjustment .....	17
1.5.f Schematics .....	17
1.5.g Connecting an External Controller .....	18
1.5.h Programming for an External Controller .....	19
1.6 Service Level Programming .....	21
1.6.a Service Level Factory Defaults .....	21
1.6.b Enter Service Level Programming .....	22
1.7 Cleaning Equipment After Installation .....	24
<b>2 - Operation</b> .....	<b>26</b>
2.1 Display Door .....	26
2.2 Energizing Chiller .....	26
2.3 Wake Up Chiller .....	26
2.4 Display Panel .....	26
2.4.a Buttons .....	27
2.4.b Display .....	27
2.4.c Indicator Lights .....	27
2.5 User Level Programming .....	28

---

2.5.a User Level Factory Defaults .....	28
2.5.b Selecting Celsius or Fahrenheit .....	29
2.5.c Setting Operating Mode .....	29
2.5.d Setting Thermostats .....	29
2.5.e User Lock Option (Enable) .....	30
2.5.f User Lock Option (Disable) .....	31
2.5.g Using Pass Code to Access Chiller .....	31
2.5.h Operating Chiller (With an External Controller) .....	32
<b>3 - Maintenance</b> .....	<b>33</b>
3.1 Water Chemistry .....	33
3.2 Planned Maintenance .....	33
3.3 Winterizing .....	34
<b>4 - Appendix</b> .....	<b>37</b>
4.1 Identifying Model Specifications .....	37
4.2 Weights .....	37
4.3 Cooling Recommendations .....	38
4.4 Available Accessories .....	38
<b>5 - Troubleshooting</b> .....	<b>40</b>
5.1 Fault Codes .....	40
5.2 Issues and Resolutions .....	42

**Contacting AquaCal AutoPilot, Inc.**

**For further assistance, please contact the distributor or installer of this product.**

If unavailable, please contact AquaCal® for a partner in your area. To better assist you, please have the chiller model and serial number available. See "Identifying Model Specifications" on page 37.




<b>Product Information:</b>	
<b>Website</b>	www.AquaCal.com
<b>Phone</b>	(1) 727-823-5642
<b>Hours</b>	8-5 pm, Eastern M-F

<b>Service Information:</b>	
<b>Website</b>	www.AquaCal.com/request-heat-pump-service/


**SAFETY INSTRUCTIONS**

- For personal safety, and to avoid damage to equipment, follow all safety instructions displayed on the equipment and within this manual. Repair and service of chiller must be performed by an authorized service center.
- Warranties may be voided if the equipment has been improperly installed, maintained or serviced.
- If service is deemed necessary, please see "Contacting AquaCal AutoPilot, Inc." on page 1.

**SAFETY SIGNALS**  
*Throughout this document, safety signals have been placed where particular attention is required.*

	- Failure to heed the following will result in injury or death.
	Failure to heed the following may result in injury or death.
	Failure to heed the following may result in damage to equipment.

When installing and using your chiller basic safety precautions must always be followed, including the following:

- |   |   |
|---|---|
|  | - Failure to heed the following will result in injury or death. |
|---|---|
- The chiller utilizes high voltage and rotating equipment. Use caution when servicing.

**⚠ WARNING**

Failure to heed the following may result in injury or death.

- Installation and repairs must be performed by a qualified technician.
- The chiller contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained and / or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.
- Improper water chemistry can present a serious health hazard. To avoid possible hazards, maintain pool / spa water per standards detailed in this document.
- Prolonged immersion in water colder than normal body temperature may cause a condition known as Hypothermia. The symptoms of Hypothermia include shivering (although as hypothermia worsens, shivering stops), clumsiness or lack of coordination, slurred speech or mumbling, confusion and poor decision-making, drowsiness or low energy, lack of concern about personal welfare, progressive loss of consciousness, weak pulse and slow or shallow breathing. In addition, persons having an adverse medical history, or pregnant women, should consult a physician before immersing in a cold body of water. Children and the elderly should be supervised by a responsible adult.

**NOTICE**

Failure to heed the following may result in damage to equipment.

- Maintain proper water chemistry in order to avoid damage to pump, filter, pool shell, etc.
- Water flow exceeding maximum flow rate requires a bypass. Damage due to excessive water flow will void warranty.

**SAVE THESE INSTRUCTIONS**

## 1 - Installation

### **WARNING**

Failure to heed the following may result in injury or death.

- Installation of this equipment by anyone other than a qualified installer can result in a safety hazard.
- The information contained throughout the "Installation" section is intended for use by qualified installation technicians familiar with the swimming Pool / Spa safety standards.


### **NOTICE**

Failure to heed the following may result in damage to equipment.


- Failure to protect equipment against corrosive conditions will adversely affect the life of the equipment and will void equipment warranty.

## 1.1 Dimensions

### (TropiCool® TC1000)



### (TropiCool® TC500)



## 1.2 Positioning Equipment

### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not install equipment inside of a building.

## Outdoor Use Only

### **Do not install equipment inside of a room or building.**

- Chillers require unobstructed air flow for proper operation. Chillers should never be installed indoors or in a location where air flow is restricted. See "Clearances" on page 5.

## Controlling Irrigation and Rainwater Runoff

- Irrigation water may damage chiller components. Direct irrigation water away from the chiller.
- The chiller will withstand normal rainfall. Do not allow a roof slope to direct rainwater onto the chiller. Have a gutter installed on the roof edge to direct this water away from the chiller. Or install the chiller in another location.

## **Planning for Condensation**

The chiller can produce a large amount of condensation. The amount of water depends on air temperature and humidity.

- Install the chiller with enough height to allow for water drainage.
- Plan for water drainage as needed. See "Condensation Drain Kit (# STK0202)" on page 38.

## **Mounting Pad Requirements**

- Build the chiller pad out of concrete or other code-approved material.
- Confirm the pad can support the weight of the chiller. See "Weights" on page 37.
- Elevate the pad enough to allow for drainage.
- Make sure the pad is flat and level.
- Have the pad extend at least 6 inches from the chiller base in all directions.
- Do not install the chiller on soil or grass.
- Do not allow the chiller base to touch the building's foundation.
- Do not place the chiller directly on a concrete floor. This can cause noise to be transmitted to an occupied space. If necessary install vibration dampers between the heat pump base and floor.
- Equipment pad must meet all requirements of authorities having code-related jurisdiction.


## **Anchoring to Pad**

- Follow all applicable local, state, and national requirements regarding wind load anchoring.
- The shipping brackets used to secure the chiller to the pallet are approved mounting (hurricane) brackets. They should be used to anchor the chiller to the pad.
- If needed, contact AquaCal® to obtain anchoring kit information. Please have the chiller model number and serial number when requesting support. See "Identifying Model Specifications" on page 37.



### 1.3 Clearances

- Proper air circulation is required for the chiller to operate efficiently. The following diagrams show the minimum clearances required for the proper operation of the chiller.
- Avoid storing chemical containers near the chiller. The chemicals can cause equipment damage.
- Avoid placing objects near or on top of the chiller. This includes shrubbery and lawn furniture. These objects will reduce performance and efficiency and hinder maintenance access.



### 1.4 Plumbing

#### 1.4.a Plumbing Requirements

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the equipment from being properly winterized.
- The chiller must receive water flow within the specified minimum ranges under worst-case conditions such as a fouled water filter.
- Failure to provide clean filtered water to the chiller can void product warranty.
- Water flow exceeding maximum flow rates will negatively affect the total pool filtration performance and may damage the chiller. This will not be covered under equipment warranty. See "Water Flow Rates" on page 11.
  - Install a bypass valve whenever water-flow may exceed maximum rating.
    - See "5 lb Bypass Valve Kit (# STK0135)" on page 38.
    - For additional guidance testing water flow rates, please contact AquaCal®.


## 1.4.b Plumbing Diagrams

Plumbing diagrams are provided in this section as a planning guide to the sequence of equipment, valves, and fittings.

- The basic plumbing configurations for typical installations are shown.
- If the installation does not closely follow any of the supplied plumbing diagrams, AquaCal® Technical Support is available for installation advice and guidance.
- Confirm water provided to chiller is clean and filtered.


### Chiller with water flows equal or less than maximum listed flow rate

See "Water Flow Rates" on page 11.




### Chiller with water flows greater than maximum listed flow rate


See "Water Flow Rates" on page 11.




### Chiller with Spillover Spa (One filter Pump)




### Chiller with Spillover Spa (Two filter Pumps)




### Chiller with Solar Panels in Plumbing Circuit




## Chiller with Gas Heater backup



## Multiple Air Source Chillers



## Multiple Air Source Chillers (Reverse Return Detail)



### 1.4.c Plumbing Diagrams


Plumbing diagrams are provided in this section as a planning guide to the sequence of equipment, valves, and fittings.

- The basic plumbing configurations for typical installations are shown.
- If the installation does not closely follow any of the supplied plumbing diagrams, AquaCal® Technical Support is available for installation advice and guidance.
- Confirm water provided to chiller is clean and filtered.

## Air Source Chiller Plumbing Diagrams


### Chiller with water flows equal or less than maximum listed flow rate

See "Water Flow Rates" on page 11.



### Chiller with water flows greater than maximum listed flow rate

See "Water Flow Rates" on page 11.



## 1.4.d Water Connections to Chiller


- Chiller union sizes are specified on diagrams.
- Connections to site plumbing are made via PVC solvent cement to the female slip socket of the plumbing unions.
- Plumbing unions are available from AquaCal®. See "Available Accessories" on page 38.

### **NOTICE**


Failure to heed the following may result in damage to equipment.

- Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the equipment from being properly winterized.

### TropiCool® TC500




### TropiCool® TC1000



### 1.4.e In-Line Chlorine Feeders

Place in-line chlorinators downstream from the chiller and as low in elevation as possible. If an erosion type feeder is used, always install a Hartford Loop to protect internal chiller components.

**Chiller with Hartford Loop**



### 1.4.f Water Flow Rates

Maintain water flow rates as indicated. Please note, these specifications relate to the chiller only. Code-specified whole system turnover rates must be satisfied.

**NOTICE**

Failure to heed the following may result in damage to equipment.

- Water flow exceeding maximum flow rates will negatively affect the total pool filtration performance and may damage the chiller. This will not be covered under equipment warranty.

MODEL	HEAT EXCHANGER TYPE	FLOW RATES	
		MINIMUM	MAXIMUM
TC500	Titanium Tube-in-Tube	20 GPM	45 GPM
TC1000	Titanium ThermoLink®	30 GPM	70 GPM

**PLEASE NOTE -**

If minimum flow rates are not met, chiller performance is reduced and performance will suffer. Internal safety devices may deactivate the chiller with the following errors:

- **HP** and **HP5**
- or (if equipped) error codes of **LP** and **LP5**

- Operate water filtration devices per manufacturer's specifications. Dirty filters can cause a reduction of water flow to the chiller. An increase of 7-10 psi higher than the clean filter pressure typically reduces flow rates. This requires the filter to be cleaned or back-washed.
- Keep baskets free of debris. A large quantity of debris in the pump and skimmer baskets can reduce water flow.
- Check for improper valve settings. A partially closed valve after the filter, or a full-open bypass around the chiller, will cause insufficient water flow through the chiller.
- The maximum static pressure (or operating pressure) is 50 pounds-per-square-inch (PSI). These specifications relate to the chiller only.
- Code-specified whole system turnover rates must be satisfied.

#### 1.4.g Maintaining Ability to Winterize

Do not glue the threaded portion of the unions. The unions are used to decouple the chiller from the plumbing system during hard freeze conditions.

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the chiller from being properly winterized.

#### 1.4.h Adjusting Water Pressure Switch

Adjust water pressure switch when chiller attempts to operate without water flow.

Before attempting any adjustments confirm the following :

- The filter is clean.
- Filter pump is operating.
- The valves are set to direct the appropriate amount of water through the chiller. See "Water Flow Rates" on page 11.
- *FLD* is displayed (or displays intermittently).

#### **WARNING**

Failure to heed the following may result in injury or death.

- Water Pressure Switch adjustment procedure to be performed by experienced service personnel only; procedure must not be attempted by individuals lacking adequate electrical and mechanical experience.


#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- If after water pressure switch adjustment the chiller continues to operate with the filter pump off, readjust water pressure switch to ensure chiller will not run without water flow.



1. Remove chiller access panel. See "Access Panels" on page 16.
2. Locate the water pressure switch. It will be outside and along the bottom edge of the electrical enclosure. Exact location varies by model.
3. Activate filter pump.
4. Apply power to chiller.
5. Slowly rotate the adjustment wheel on the switch. Keep turning the wheel until the chiller indicates it is receiving water. The display will no longer display the **FLD** code.



6. Deactivate filter pump. If correctly adjusted, the chiller will deactivate and the display will show the **FLD** code.
7. Re-install chiller access panel.
  - If chiller continues to operate without water flow, contact AquaCal®.
  - Site-specific factors may require the installation of an external flow switch. See "Available Accessories" on page 38.

## 1.5 Electrical

### 1.5.a Electrical Requirements

#### **⚠ WARNING**

Failure to heed the following may result in injury or death.

- The information contained in this section is intended for use by qualified electricians familiar with electrical service-industry safety standards and methods.
- Locate the equipment disconnect as near to the chiller as possible. Always satisfy applicable codes and standards.
- Never mount power-disconnects directly to the chiller.
- In sizing power wiring, be especially aware of up-sizing requirements necessary due to wiring distances. Always satisfy applicable codes and standards.
- AquaCal® chillers are designed to use copper conductors, only. Do not use aluminum wire.
- Multiple chillers installed at the same site may benefit from automatic sequencing controllers (ASC) to avoid excessive power drops at start-up. See "Available Accessories" on page 38.

## Electrical Standards

Standards	Title
<b>NFPA 70</b>	The electrical installation must conform to the current version of the NEC, and all applicable local and state codes
<b>NFPA 70 Article 440</b>	Standard for Safety for Electric Spas, Equipment Assemblies, and Associated Equipment
<b>NFPA 70 Article 680</b>	Standard for Safety for Swimming Pool Pumps, Filters, and Chlorinators
<b>IEC 60335-1-2001</b>	Household and similar electrical appliances - Safety - General Requirements
<b>IEC 60335-2-40 2006</b>	Household and similar electrical appliances - Safety – Particular requirements for electrical heat pumps, air-conditioners, and dehumidifiers
<b>UL1995 &amp; CSA C22.2 236-05</b>	Heating and cooling equipment

Table 1 - Standards

## Grounding and Bonding

Follow local code requirements for properly grounding and bonding chiller equipment.

- A bonding lug has been provided on the lower right hand corner of the front access panel.

## Surge Suppression

The use of approved commercial surge protectors is strongly recommended.

## Sizing the Electrical Service

Refer to equipment data plate for specific information required to size electrical service and over-current protection of chiller. Sizing is based on data plate information, wire size, wiring devices, and over-current protection per applicable local codes and standards. See "Identifying Model Specifications" on page 37.

## Minimum and Maximum Operating Voltage

The chiller must operate within specified voltages.

### NOTICE


Failure to heed the following may result in damage to equipment.

- Operating equipment under higher or lower voltage conditions may result in damage to your compressor, motors or other electrical components. This damage will not be covered by product warranty.
1. Measure site voltage. The site voltage **MUST** be measured under “FULL LOAD” conditions. Activate all equipment using the same electrical panel as the chiller.
  2. If measured site voltage is outside listed ranges, immediately deactivate equipment until site conditions have been corrected. If unsure of chiller equipment rating, please see "Identifying Model Specifications" on page 37.


Equipment Rating	Minimum Site Voltage	Maximum Site Voltage
<b>A Voltage</b> (208 to 230 Volts) Single Phase 60 hertz	200 Volts	253 Volts
<b>B Voltage</b> (208 to 230 Volts) 3 phase 60 hertz	200 Volts	253 Volts
<b>D Voltage</b> (380 to 420 Volts) 3 phase 50 hertz	361 Volts	441 Volts
<b>G Voltage</b> (460 Volts) 3 phase 60 hertz	437 Volts	483 Volts
<b>H Voltage</b> (200 to 240 Volts) Single Phase 50 hertz	180 Volts	264 Volts

## 1.5.b Incoming Power Access Holes

( TC1000)




( TC500)




## 1.5.c Access Panels

### TC500



### TC1000



## 1.5.d Verifying Transformer Setting


Transformer voltage must be confirmed and set correctly depending on the measured voltage found on the site. Incorrect settings may cause chiller damage. The following procedure will allow the installer to set the chillers transformer for the appropriate site voltage.

### **WARNING**

Failure to heed the following may result in injury or death.

- The information contained in this section is intended for use by qualified technicians, familiar with electrical service-industry safety standards and methods.
1. Turn chiller on by adjusting the thermostat to call for cooling. If more than one chiller is on site, turn them all on. Allow time for all chiller compressors to activate.
  2. Measure the running site voltage.
  3. Confirm transformer tap is set for the measured site voltage. If more than one voltage tap is shown, select the voltage nearest to the running site voltage.

### Example of chiller transformer (Varies between models)



### **PLEASE NOTE -**

- If more than one voltage is shown on the equipment's data plate, the factory default setting is usually the higher voltage on the transformer.
- As an example, a "208/230" voltage will be set to "240" from the factory.

## 1.5.e Three-Phase Adjustment

### **WARNING**

Failure to heed the following may result in injury or death.

- The information contained in this section is intended for use by qualified technicians, familiar with electrical service-industry safety standards and methods.

If a three-phase unit fails to operate at start up, the orientation of the line voltage "field" wiring may need to be adjusted.

- The phase monitor is located inside the electrical panel.

1. Deactivate power to the unit. **Confirm that power is off to all three legs using an electrical test meter set for the correct voltage.**
2. Switch position of the incoming power wires at each leg as follows, re-connect power, and attempt to restart the unit. If the unit fails to start, disconnect power. Verify off and proceed to next leg.
  - Switch incoming power wires at L1 and L2 on the line side to the contactor.
  - Switch incoming power wires at L1 and L3 on the line side to the contactor.
  - Switch incoming power wires at L2 and L3 on the line side to the contactor.
3. When chiller starts, disconnect power and verify off. Then confirm all line voltage connections are securely tightened. Reconnect power.
  - If chiller does not start, contact AquaCal® for further assistance. See "Contacting AquaCal AutoPilot, Inc." on page 1.

**Three-Phase Monitor**



## 1.5.f Schematics

Schematics are located on the inside of the equipment access panel.

### **PLEASE NOTE:**

- Specifications are subject to change without notice.
- Schematics are available by calling AquaCal® Customer Support. See "Contacting AquaCal AutoPilot, Inc." on page 1.
  - Please have the complete model and serial number available.
  - See "Identifying Model Specifications" on page 37.

## 1.5.g Connecting an External Controller

To support a direct connection to an external controller, AquaCal® chillers are equipped with optional terminal blocks. These terminals are on the microprocessor located on the low-voltage side of the electrical enclosure.

### ⚠ WARNING

Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.
- Deactivate power while routing wiring to control board.

### NOTICE


Failure to heed the following may result in damage to equipment.

- The wire size connecting the controller must be 16-gauge, 2-conductor or larger, low-voltage wire.
- Use direct connection (**dry contact**) provided on the microprocessor for external controllers.

Please confirm the type of external controller to be installed and follow the appropriate instructions.

- A **two-wire** controller (**with an internal thermostat**). *The user can set and adjust the temperature at the controller's screen.*
- A **three-wire** controller (**with an "OFF" position**). *The user adjusts the temperature at the heat pump. The user can select pool or spa mode or turn off the heat pump using the controller.*
- A **three-wire** controller (**without an "OFF" position**). *The user adjusts the temperature at the heat pump. The user can select pool or spa mode, but must turn off the heat pump at the heat pump display panel.*

### Dry Contact Connection Points to the Microprocessor



### Two-wire controller (with internal thermostat):

1. Deactivate power to chiller.
2. Remove chiller electrical access panel.
3. Route the control wiring to the low voltage side of the electrical enclosure. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
4. Connect the controller wires to the microprocessor as follows:
  - Connect one wire to "Y".
  - Connect other wire to "Z".
  - The polarity of the wire is not important.
5. Reattach chiller access panel.
6. Apply power to chiller.
7. Program chiller for a two-wire controller. See "Using JAO interface" on page 19.

### Three-wire controller (with "OFF" position):

1. Deactivate power to chiller.
2. Remove chiller electrical access panel.
3. Route the control wiring to the low voltage side of the electrical enclosure. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
4. Connect the controller wires to the microprocessor as follows:
  - Connect "Low" or "Pool" wire to "X".
  - Connect "High" or "Spa" wire to "Z".
  - Connect "Common" wire to "Y".
5. Reattach chiller access panel.
6. Apply power to chiller.
7. Program chiller for a three-wire controller. See "Using JAO interface" on page 19.

### Three-wire controller (without an "OFF" position):

1. Deactivate power to chiller.
2. Remove chiller electrical access panel.
3. Route the control wiring to the low voltage side of the electrical enclosure. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
4. Connect the controller wires to the microprocessor as follows:
  - Connect "Common" wire to one terminal of "FS2".
  - Connect "Spa" to other terminal of "FS2".
  - The third wire is not used.
5. Reattach chiller access panel.
6. Apply power to chiller.
7. Program chiller for an external controller. See "Using FS2 interface" on page 20.

## 1.5.h Programming for an External Controller

Configure chiller for external control.

### Using JAO interface



Press "Up" and "Down" buttons simultaneously until **CF 1** appears.



Press "Pool / Spa" button until **LOC** is displayed.



Press "Up" or "Down" to passcode. Default is "17".



Press "Pool / Spa" button once.




Press the "Pool / Spa" button until **JAO** is displayed.



Press "Up" or "Down" button.

- "0" - none
- "2" - two-wire
- "3" - three-wire


## Using F52 interface




Press "Up" and "Down" buttons simultaneously until **CF 1** appears.



Press "Pool / Spa" button until **LOC** is displayed.




Press "Up" or "Down" to passcode. Default is "17".



Press "Pool / Spa" button once.



Press the "Pool / Spa" button until **F52** is displayed.



Press "Up" or "Down" button.

- "0" - none
- "1" - External



## 1.6 Service Level Programming

### NOTICE

Failure to heed the following may result in damage to equipment.

- Service Level Programming must only be attempted by authorized personnel.
- Unauthorized adjustments in the Service Menu (beyond the **LOC** menu) may void the chiller's warranty.
- Resetting the microprocessor to access a locked keypad will reset all settings to factory default including any installer-entered configuration. Re-programming all custom site condition settings will be required when using this reset. See "Reset to Factory Defaults Settings" on page 23.
- For further assistance, please see "*Contacting AquaCal AutoPilot, Inc.*" on page 1.

#### PLEASE NOTE -

Before changing multiple program options, it is recommended that the user lock option be disabled. See "User Lock Option (Disable)" on page 31.

The lockout option can be re-enabled after all changes are completed.

### 1.6.a Service Level Factory Defaults


Certain programming options have been preset at the factory. These options can be overwritten for certain site-specific conditions.

Table 2 - Default Program Parameters Chart

Code	Description	Default Value	Range
<b>CFD</b>	Call-Flex Options	0	Set to off at the factory.
<b>dbP</b>	Pool Dead-Band Differential	1°	Set at factory. Do not adjust.
<b>dbS</b>	Spa Dead-Band Differential	1°	Set at factory. Do not adjust.
<b>dEL</b>	Compressor Time Delay	1 (4 minutes)	Set to on (at 4 minutes) at the factory. Do not adjust.
<b>dSC</b>	Defrost Sensor	Factory Calibrated	Set at factory. Do not adjust.
<b>dFd</b>	Defrost Delay	Factory Calibrated	Set at factory. Do not adjust.

Code	Description	Default Value	Range
F52	Flow Switch / Automatic Thermostat Switching Option	0	0 = "No Switch" 1 = "Enable Switch"
JAO	External Controller	0	0 = "No Controller" 2 = "Two Wire Controller" 3 = "Three Wire Controller"
LDC	Service Level Entry Point	50	00 - 99
t5C	Water Sensor	Factory Calibrated	Set at factory. Do not adjust.


### 1.6.b Enter Service Level Programming




Press "Up" and "Down" buttons simultaneously until **CF 1** appears.



Press "Pool / Spa" button until **LDC** is displayed.




Press "Up" or "Down" to passcode. Default is "17".



Press "Pool / Spa" button once.

## Programming for a Relay Switch


Configure chiller for a relay or flow switch. This can provide automatic pool/ spa thermostat switching.




Press "Up" and "Down" buttons simultaneously until **CF 1** appears.



Press "Pool / Spa" button until **LOC** is displayed.




Press "Up" or "Down" to passcode. Default is "17".



Press "Pool / Spa" button once.



Press the "Pool / Spa" button until **FS2** is displayed.



Press the "Up" or "Down"  
 • "0" - not active  
 • "1" - enable

Once the **FS2** feature has been activated the "POOL / SPA" button will no longer function. The relay or flow switch is used to change between the pool and spa temperature settings.

## Reset to Factory Defaults Settings

### NOTICE

Failure to heed the following may result in damage to equipment.

- Using this option will reset ALL settings to their factory defaults including external controller settings and sensor calibrations. **DO NOT** perform this operation if unsure of site specific settings or how to reset them on the chiller.
- If a qualified technician is unavailable, please see "Contacting AquaCal AutoPilot, Inc." on page 1.

1. Simultaneously Press "Pool / Spa" button and "Up" button until the display shows **888**.
2. Release buttons. Reset is complete.



## 1.7 Cleaning Equipment After Installation

Installer - If you need to clean equipment after installation, please use the following guidelines.

### **WARNING**

Failure to heed the following may result in injury or death.

- Possible electric shock hazard - Deactivate power to all electrical devices on the pad when washing chiller. Do not restore electrical power until equipment is completely dry.

### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not use a pressure cleaner to wash chiller. Damage to chiller components may result. If using a hose-end spray nozzle adjust spray pattern to low strength only.
- Do not spray water directly into the interior of the chiller; damage to components may result.
- Do not use chemicals on the display panel.

### Cleaning

1. Wash outside cabinet using a low-pressure water hose. A high-pressure water stream will cause damage to the aluminum fins of the chiller. This damage is not covered under product warranty.
2. While the chiller is still wet, use an approved cleaning agent to clean the exterior of the chiller. **Do not use chemicals on the display panel.**
3. Use a detergent-dampened cloth to wipe the chiller's exterior cabinet.
4. Flush all exterior with fresh water using a low-pressure water hose.
5. Dry the exterior cabinet using a soft cloth being careful not to damage evaporator fins being careful not to damage condenser fins.

<b>APPROVED CLEANING AGENTS*</b>
Fantastic <sup>®</sup>
Formula 409 <sup>®</sup>
Cascade <sup>®</sup>
All Power Plain Detergent (3% Solution)

Table 3 - Cleaning Agents

### Polishing

1. Polish the chiller's cabinet panels using an approved polishing agent and following the manufacturer's instructions. Do not use chemicals on the display panel.
2. Rinse the chiller panels with fresh water, wipe, and buff panels using a dry soft cloth.
3. Allow chiller interior and surrounding equipment to "air-dry" for several hours prior to restoring electrical power.

<b>APPROVED POLISHING AGENTS*</b>
Simoniz <sup>®</sup> Wax
Glo-Coat <sup>®</sup>
Aarmor All <sup>®</sup> Protectant

Table 4 - Polishing Agents


- The trademarks used in approved cleaning and polishing agents are property of their owners and are not related to AquaCal®.

## 2 - Operation

### 2.1 Display Door

The display panel is located in a door compartment on the front of the chiller. This compartment is designed to protect the display against harsh weather. It can also be padlocked for extra security.

- Press the **bottom** of the panel to open the display panel door.
- To close, push the display panel up. Then press the **bottom** of the panel in until a clicking noise is heard.



### 2.2 Energizing Chiller


Activate power at external fuse box or the breaker box.

- The chiller performs a lamp test.
- The display reads **BBB**.
- The chiller then displays as normal. See "Display" on page 27.

### 2.3 Wake Up Chiller

The chiller's control panel has a sleep mode. This is used to prevent rain that hits the display from making unwanted setting changes.

To wake up the control panel, tap a button on the display until it illuminates. Then slowly slide a finger across the buttons.




- The code **UnL** will briefly appear. Then either **FLO** or the water temperature will display.

### 2.4 Display Panel

The following information outlines the operation for a standard installation.

#### Display Panel



## 2.4.a Buttons

Buttons	Description
<b>Display Lock</b>	Sliding your finger across the buttons from left to right will temporarily disable the display lock.
<b>Pool / Spa</b>	Select either the pool or the spa thermostat.
<b>Up Arrow</b>	Used to increase temperature set point and navigate through menu options.
<b>Down Arrow</b>	Used to decrease temperature set point and navigate through menu options.
<b>Mode</b>	Select chiller's operating mode.

## 2.4.b Display

Display	Description
<b>75</b>	The chiller is on and displaying the current water temperature. In this example 75° F is displayed.
<b>FLO</b>	No water flow is detected. The filter pump is off or chiller is not receiving correct water flow.
<b>OFF</b>	The chiller has been turned off via the mode selector button or the temperature set point has been lowered below 45° F.
<b>BBB</b>	The control program is initializing. This displays only as power is applied to the chiller.
<b>CF I</b>	Select water temperature format (in either Celsius or Fahrenheit).
<b>ULC</b>	Enable chiller lockout feature.
<b>ELC</b>	Select pass code to lock the keyboard.
<b>LDC</b>	This is a Service Entry Point (not intended for use by the owner). The <b>LDC</b> code permits service personnel to enter a factory pass code to access adjustable calibration and site dependent setup parameters. Service adjustments are available to authorized installation and service personnel, only.

## 2.4.c Indicator Lights

Indicators	Description
<b>Pool</b>	The Chiller is referencing the pool thermostat.
<b>Spa</b>	The Chiller is referencing the spa thermostat.
<b>Cooling</b>	Indicates the unit is cooling the water. Please note - the compressor must be operating before this light will illuminate.
<b>Water Temp</b>	Indicates current water temperature.
<b>Desired Temp</b>	Indicates temperature set point is displayed. This is displayed when "UP" or "DOWN" is selected.

## 2.5 User Level Programming

### 2.5.a User Level Factory Defaults

Certain programming options have been preset at the factory. These options can be overwritten for site-specific conditions.

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Unauthorized adjustments in the Installer Menu (beyond the **LDC** menu) may void the chiller's warranty.
- For further assistance, please see "*Contacting AquaCal AutoPilot, Inc.*" on page 1.

Table 5 - Factory Defaults


Code	Description	Default Value	Range
<b>OFF</b>	Chiller is deactivated.	<b>OFF</b>	
<b>COO</b>	Cool water to point set on thermostat.		
<b>ACH</b>	Set to maintain a water temperature set on the thermostat.		
<b>CF1</b>	Celsius / Fahrenheit Selection	1	0 = Celsius 1 = Fahrenheit
<b>ELC</b>	Enter Lock Code	0	0 - 99
<b>ULC</b>	User Lock Code	0	0 = "User Lock Disabled" 1 = "User Lock Enabled"



## 2.5.b Selecting Celsius or Fahrenheit



Press and Hold "UP" and "DOWN" until **CF 1** displays.




Press "UP" or "DOWN" button to select.

"0" - Celsius  
"1" - Fahrenheit

## 2.5.c Setting Operating Mode

1. Press "Mode / Enter" button until desired mode is displayed.
2. After a certain amount of time, the display will show the selected mode and current water temperature.
  - Cooling Mode - After fan and compressor starts, the blue "Cooling" light will activate.
  - Off - The chiller will indicate it is deactivated. The current water temperature will be displayed.




Cooling Mode




Deactivate Chiller

**Heating / Cooling modes only available on select equipment. Confirm heat pump features before setting a mode.**


## 2.5.d Setting Thermostats



Select "POOL" or "SPA"



Press "UP" or "DOWN" to the desired temperature.




- The cooling indicator will illuminate when cooling the water.

## 2.5.e User Lock Option (Enable)

The user-lock feature allows the chiller display panel to be "locked". This can prevent unauthorized temperature adjustments in commercial applications.

- Do not confuse a user-lock with the display lock. See "Wake Up Chiller" on page 26.
- If **LDC** is briefly displayed, followed by a "0", the chiller is already locked.
- If the user-lock code has been misplaced, please contact AquaCal® for further assistance.



Hold "UP" and "DOWN" until **CFI** displays.




Press "POOL / SPA" button until **ELC** is displayed.




Press "UP" or "DOWN" button to change or add a numerical password



Press "POOL / SPA" button to save the password.




Press "POOL / SPA" button until **ULC** is displayed.




Press "Up" button till "1" is displayed to enable.

## 2.5.f User Lock Option (Disable)




Use "UP" button to enter existing password.



Press "Pool / Spa" button to unlock.



Hold "UP" and "DOWN" buttons until **CF 1** is displayed.



Press "POOL / SPA" button until **ULC** is displayed




Press "DOWN" button until "0" is displayed.

## 2.5.g Using Pass Code to Access Chiller

If **LOC** is briefly displayed when attempting to change a chiller's settings followed by a "0", the chiller is in a user-lock mode. A numerical pass code is required to proceed.



Press "UP" or "DOWN" arrow to enter pass code.



Press "POOL / SPA" button to unlock.

### **NOTE -**

- After ten seconds of inactivity, the chiller's display lock will activate. See "Wake Up Chiller" on page 26.
- If the user-lock code has been misplaced, please contact AquaCal® for further assistance.

## 2.5.h Operating Chiller (With an External Controller)

### Controller with an internal thermostat control

#### Activating Chiller

1. Set the desired temperature at the external controller.
2. Use the external controller to select either the "Pool" or "Spa" to heat.

#### Deactivating Chiller

- Set the external controller to "OFF".

Please note - If equipped, the chiller's cooling function **will be disabled** when using this type of controller.

If the cooling function is needed, the chiller must be temporarily reprogrammed for local control.

- Set the chiller to operate with external control temporarily set to "none".
- See "Programming for an External Controller" on page 19.
- It is OK to leave external controller wires in place while the chiller is set for local control.

### Controller with 2 positions - ("Pool" and "Spa" - no internal thermostat control)

#### Activating Chiller

1. Set the desired temperatures on the chiller thermostats. See "Setting Thermostats" on page 29.
2. Use the external controller to select either the "Pool" or the "Spa" thermostat.
  - *Rapid movement between thermostats without a "rest" between each change can cause a missed signal by the chiller.*

#### Deactivating Chiller

- Go to the heat pump and set the mode to "OFF". See "Setting Operating Mode" on page 29.

Please note - If equipped, the chiller's cooling function **will be disabled** when using this type of controller.

If the cooling function is needed, the chiller must be temporarily reprogrammed for local control.

- Set the chiller to operate with external control temporarily set to "none".
- See "Programming for an External Controller" on page 19.
- It is OK to leave external controller wires in place while the chiller is set for local control.

### Controller with 3 positions - ("High", "Low", and "Off" - no internal thermostat control):

#### Activating Chiller

1. Set the desired temperatures on the chiller thermostats. See "Setting Thermostats" on page 29.
2. Use the external controller and select the "High" or "Low" thermostat.
  - *When changing between thermostats, select "Off" first. Then select desired thermostat.*
  - *Rapid movement between thermostats without a "rest" between each change can cause a missed signal by the chiller.*

#### Deactivating Chiller

- Set the external controller to "OFF".

### 3 - Maintenance

#### 3.1 Water Chemistry

Check water chemistry regularly and maintain within recommended levels. Standards vary in different residential and commercial applications. Follow all local applicable codes.

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not allow water to flow through chiller when refinishing or acid washing a pool. Either use an installed bypass to route water away from chiller or deactivate filter pump.
- To avoid damage to equipment, monitor and maintain chemistry within recommended levels.

<b>CHEMISTRY LEVEL CHART (RESIDENTIAL)</b>		
<b>CHEMICAL</b>	<b>POOLS</b>	<b>SPAS</b>
<b>Chlorine</b>	1.0 – 3.0 ppm	3.0 – 5.0 ppm
<b>Bromine</b>	2.0 – 6.0 ppm	2.0 – 6.0 ppm
<b>Cyanuric Acid</b>	30 – 50 ppm	30 – 50 ppm
<b>pH</b>	7.4 – 7.6 ppm	7.4 – 7.6 ppm
<b>Total Alkalinity</b>	80 – 120 ppm	80 – 120 ppm
<b>Calcium Hardness</b>	200 – 400 ppm	150 – 250 ppm
<b>Total Dissolved Solids*</b>	0 – 1,500 ppm	1,500 ppm above start-up of total dissolved solids in spas

\* Salt from a chlorine generator is not included in Total Dissolved Solids.

#### 3.2 Planned Maintenance

An annual inspection and maintenance program is strongly recommended starting no later than one year after installation of the chiller. In harsh environments or coastal areas a bi-annual inspection is recommended. See recommended inspection checklist.

AquaCal® can perform this service in limited areas. Contact Customer Support for more information.

#### **WARNING**

Failure to heed the following may result in injury or death.

- Annual inspection and service must be performed by a qualified chiller specialist in order to prevent physical injury or damage to equipment. For tasks requiring handling refrigerant, an HVAC license is required.

<b>Recommended Inspection Checklist:</b>
1. Clean Evaporator Coil
2. Clean Condenser Coil
3. Check Contactor Points
4. Check Fan Capacitor Values
5. Check Fan Blade Clearances
6. Clean Chiller Cabinet
7. Check Flow / Pressure Switch
8. Apply Rust Inhibitors (As applicable)
9. Verify / Check Air Flow Delta
10. Verify / Check Water Flow Delta
11. Check Fan Motor Amperage Draw
12. Check and Clear Condensate Drains
13. Check Compressor Capacitor Values
14. Check Compressor Amperage Draw
15. Check Internal Electrical Connections
16. Check Operating Refrigerant Pressures (As Applicable)
17. Check Ambient and Water Temperature Sensors
18. Check Proper Line and Control Voltage to Unit
19. Identify Insect and Rodent Issues with Unit
20. Identify Environmental Conditions of Concern (Run-Off, Sprinklers, etc.)
21. Perform Operating Orientation (As Applicable)

### 3.3 Winterizing

Failure to properly winterize the chiller as needed may result in serious equipment damage.

#### **⚠ WARNING**

Failure to heed the following may result in injury or death.

- Deactivate all electrical power to chiller before performing hard freeze procedures.

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Failure to winterize chiller may result in serious equipment damage. Freeze damage is not covered under the chiller warranty.
- While the plumbing connections are in the winterized condition (not fully tightened), it is imperative that water not run through the chiller. Loss of water through loose plumbing connections may result in damage to circulation pump, pool and spa structures, and other equipment.

### Light Freeze Conditions

A light freeze is when the ambient air temperature falls below 32 degrees Fahrenheit for less than 8 hours. Typically during light freeze conditions circulating (or moving) water will not freeze. Temporarily activate the filter pump for continuous operation during light freeze conditions.

### Hard Freeze Conditions

A hard freeze is when the ambient air temperature falls below 32 degrees Fahrenheit for more than 8 hours. In areas where this condition is prevalent and sustained, the chiller MUST be winterized for hard freeze conditions. Follow the correct procedure depending on the type of heat exchanger found in the chiller.

#### ***Identify Exchanger:***

1. Deactivate all electrical power to chiller.
2. Deactivate filter pump.
3. Remove front access panel. See "Access Panels" on page 16.
4. Identify heat exchanger from illustrations in this section. Then follow procedure for the appropriate heat exchanger.

### Titanium ThermoLink® Exchanger (with no Drain)

5. Reinstall front access panel.
6. Disconnect the plumbing to the chiller at connection unions (removal is counter-clockwise).
7. Allow water to drain completely from the chiller. Expect to see a lot of water drain out at first, and then a small amount to continue to drain out over a long period.
8. After chiller has fully drained, partially reconnect plumbing connection unions.
9. Winterizing is complete.
10. When ready to use chiller again, hand-tighten connection unions. Reconnect electrical power, and set the operating mode on the chiller. Activate filter pump.


**No Drain**



## Titanium Tube-in-Tube Exchanger

5. Reinstall front access panel.
6. Disconnect the plumbing to the chiller at connection unions (removal is counter-clockwise).
7. Allow water to drain completely from the chiller. Expect to see a lot of water drain out at first, and then a small amount to continue to drain out over a long period.
8. Place an air hose into the pool inlet of the chiller; wrap a clean rag around the hose to form a temporary seal.
9. Push all water from the water circuit using compressed air no stronger than 50 psig. The residual water should be forced out of the chiller's water outlet. Allow compressed air to blow into the chiller inlet for at least 15-20 seconds after the water stops coming out.
10. Repeat process on the outlet side of the chiller.
11. Partially reconnect plumbing connection unions.
12. Winterizing is complete.
13. When ready to use chiller again, hand-tighten connection unions. Reconnect electrical power, and set the operating mode on the chiller. Activate filter pump.

**Titanium  
Tube-in-  
Tube**





## 4 - Appendix


### 4.1 Identifying Model Specifications

1. Find Data Plate - The data plate is usually posted on the side of the equipment or the inside of the chiller's access plate.
2. Find the model number on the data plate. The first letters and numbers indicate the model type.
3. The complete model number identifies the equipment's specifications.

#### Data Plate Example

MINIMUM CIRCUIT AMPACITY	<input type="text"/>	MADE IN THE USA
ELEC. SERVICE: VOLTS	<input type="text"/>	PH <input type="text"/> HZ <input type="text"/>
MAXIMUM TIME DELAY FUSE OR HACR BREAKER	<input type="text"/>	5
COMPRESSOR VOLTS	<input type="text"/>	R.L.A. <input type="text"/> L.R.A. <input type="text"/>
FAN MOTOR VOLTS	<input type="text"/>	H.P. <input type="text"/> F.L.A. <input type="text"/>
REFRIGERANT: Circuit - Factory charged	<input type="checkbox"/>	Only oz/Kg <input type="text"/>
Tested to	<input type="checkbox"/>	psig High side / <input type="checkbox"/>
		psig Low side
OUTDOOR USE		
AQUA CAL, INC. A TEAM HORNER COMPANY 2737 24 <sup>TH</sup> STREET NORTH ST. PETERSBURG, FL 33713 FACTORY SERVICE 727-523-5642	MODEL NUMBER <input type="text"/>	<b>IIIBAR CODEIII</b>
	SERIAL NUMBER <input type="text"/>	<b>IIIBAR CODEIII</b>

#### Model Number Example



### 4.2 Weights

**NOTE:**

*Specifications subject to change.*

Model Type	Model Number	Install Weight
TropiCool®	TC500	215 Pounds
TropiCool®	TC1000	285 Pounds

Table 6 - Equipment Weight

### 4.3 Cooling Recommendations

The following recommendations will reduce the amount of time required to cool a pool or cold plunge application. **If unsure of equipment cooling capability, review equipment data plate.** See "Identifying Model Specifications" on page 37.

1. Confirm chiller mode has been set to cooling mode.
2. Set thermostat to desired water temperature.
3. Temporarily set the filter pump for continuous operation.
  - This will allow the Chiller the time required to cool the water at start-up.
  - After the water has reached the desired temperature, reset the filter pump to normal operating time-frames.

### 4.4 Available Accessories

Accessories may be purchased through an authorized dealer of AquaCal products.

For further assistance, please see "*Contacting AquaCal AutoPilot, Inc.*" on page 1.

#### 5 lb Bypass Valve Kit (# STK0135)

- When high flow rates are outside recommended specifications, please use this kit or an alternative bypass valve system.
- This kit can be used to control excessive water flow through the chiller. It provides automatic flow adjustments for most applications.

#### Condensation Drain Kit (# STK0202)

- Used when condensation water flow must be directed to a specific location.

#### Automatic Sequencing Controller

- An Automatic Sequencing Controller (ASC) provides easy control of all units from one lead unit and prevents the simultaneous start-up of multiple chillers.
- Site voltage drop is minimized and utilities are not subjected to large in-rush demands of electrical current.
- Part number is based on number of chillers to be controlled. Call AquaCal® for assistance with correct configuration. See "*Contacting AquaCal AutoPilot, Inc.*" on page 1.

#### External Flow Relay (Grid Flow Switch ) Kit (0040S)

- Used when the pool / spa elevation is higher than the chiller.
- Also used for automatic pool / spa thermostat switching.

***PLEASE NOTE -***

*The kit is not to be used on applications exceeding 50 PSI.*

#### Plumbing Unions:

SIZE	PART NUMBER
2 INCH	PLS2627

#### Remote Control Kit (STK0070)

- A remote (wired) control kit allows for full control of the chiller from up to 100 feet from the equipment.

## Temperature Port Kit

- This kit is used to install a temperature port.
- This port can be used to adjust water flow using Delta-T. The kit comes with port, installation components, and a temperature probe.

<b>PART NUMBER</b>
--------------------

Kit # (STK0096)
-----------------

## 5 - Troubleshooting

### 5.1 Fault Codes

A fault code indicates a specific issue or condition that will require action before the equipment can resume operating.

Please perform the following troubleshooting.

If the issue reoccurs, please see *"Contacting AquaCal AutoPilot, Inc."* on page 1.

#### **WARNING**

Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The chiller contains refrigerant under high pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

#### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Service by unauthorized personnel will void the chiller warranty.

#### **FLO Indicator**

##### **ISSUE**

Low or no water detected.

##### **RESOLUTION**

1. Confirm the filter pump is on.
2. If a multiple-speed filter pump is being used, run at a higher speed to determine if the error persists. Do not exceed maximum flow rate for your model.
3. Confirm water is not being diverted away from the chiller.
  - See "Water Flow Rates" on page 11.

#### **F5 Indicator**

##### **ISSUE**

The chiller has sensed the evaporator coil is icing up.

##### **RESOLUTION**

When ice starts to form on the coil, the compressor will stop operating while the fan continues to operate.

- The evaporator coil will begin to warm to the surrounding air temperature. When the coil's temperature rises above 38° F, the compressor is restarted and cooling resumes.
- If the coil's temperature remains below 38° F, the compressor will remain off.

#### **CEr Indicator**

##### **ISSUE**

This can indicate a loose or damaged communication cable.

##### **RESOLUTION**

A qualified technician should check the cable from control board to display assembly for a loose connection or visible damage.

### **CSE Indicator**

#### **ISSUE**

This is a control system error.

#### **RESOLUTION**

Deactivate then reactivate power to reset controls.

### **dPC or dPD Indicator**

#### **ISSUE**

Shorted or open defrost sensor.

#### **RESOLUTION**

A qualified technician should replace the defrost sensor.

### **PC or PD Indicator**

#### **ISSUE**

Shorted or open water sensor.

#### **RESOLUTION**

A qualified technician should replace the water sensor.

### **HP Indicator**

#### **ISSUE**

The refrigerant system's high-pressure switch is showing as open.

#### **RESOLUTION**

Determine if an insufficient amount of air is being supplied to the equipment.

1. Check for proper fan operation. If fan is not operating, contact AquaCal®.
2. Check for obstructed air flow around the chiller. See "Clearances" on page 5.
3. Check for dirty or blocked evaporator coil. See "Cleaning Equipment After Installation" on page 24.

### **HP5 Indicator**

#### **ISSUE**

The chiller has locked due to five **HP** (high-pressure) faults during one call for cooling.

#### **RESOLUTION**

1. Deactivate then reactivate power to the chiller to clear error.
2. Troubleshoot the high-pressure issue causing the error. See "HP Indicator" on page 41.

### **LP Indicator**

#### **ISSUE**

The refrigerant system's low-pressure switch is showing as open.

#### **RESOLUTION**

Determine if an insufficient amount of water is being supplied to the equipment.

1. Confirm the filter pump is on.
2. If a multiple-speed filter pump is being used, run filter pump at a higher speed. Do not exceed maximum flow rate for the model.
3. Confirm water is not being diverted away from the chiller.
  - See "Water Flow Rates" on page 11.
4. The water pressure switch may be incorrectly calibrated. See "Adjusting Water Pressure Switch" on page 12.

### LP5 Indicator

#### ISSUE

The chiller has locked due to five **LP** (low-pressure) faults during one call for cooling.

#### RESOLUTION

1. Deactivate then reactivate power to the chiller to clear error.
2. Troubleshoot the low-pressure issue causing the error. See "LP Indicator" on page 41.

### DEA Indicator

#### ISSUE

Incoming water temperature exceeded 110° F and the unit is locked with an **DEA** over temperature alarm. The chiller will not operate until incoming water temperature drops to 100° F or lower.

#### RESOLUTION

1. Determine if another heat source (gas heater, solar heater, etc.) is heating water being sent directly to the chiller with the **DEA** indicator. This situation will need to be corrected before continuing.
2. Rule out an incorrect reading from the water temperature sensor. Verify existing water temperature with an accurate thermometer. If chiller's sensor is inaccurate, the water temperature sensor may require replacement.

## 5.2 Issues and Resolutions

### **WARNING**

Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The chiller contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

### **NOTICE**

Failure to heed the following may result in damage to equipment.

- Service by unauthorized personnel will void the factory warranty.

Please perform the following troubleshooting.

For further assistance, please see *"Contacting AquaCal AutoPilot, Inc."* on page 1.

### Display Panel Not Responding

1. If the chiller is controlled by an external controller, confirm the external controller settings. See "Operating Chiller (With an External Controller)" on page 32.
2. If the issue is still occurring, disconnect external controller from the chiller. Then check operation at chiller.
  - If display panel responds, the problem lies with the external controller or its installation. Contact the manufacturer of the external control device.

## Chiller Not Running

1. Confirm equipment is receiving power. Is the chiller display illuminated?
  - If not, confirm the main breaker (located at the power supply panel) and the disconnect switch (located near the chiller) are both turned on.
  - If the display still does not illuminate, it is recommended that the chiller installer or electrician confirms chiller is receiving power.
2. Confirm correct mode is selected. See "Setting Operating Mode" on page 29.
3. Confirm thermostat is set correctly. See "Setting Thermostats" on page 29.
  - When cooling the water is desired, the thermostat should be set below the current water temperature.
4. If an error code is displayed, diagnose and correct the cause of the code. See "Fault Codes" on page 40.

## Chiller's Tripping Breaker

1. Have an electrician confirm breakers are in good condition and properly sized for the chiller.
2. Multiple chillers installed at the same site may benefit from special automatic sequencing controllers to avoid excessive power drops at start-up. See "Automatic Sequencing Controller" on page 38.
3. If a fault occurs immediately when the compressor starts, a qualified technician should evaluate the system.

## Chiller Won't Shut Off

### **PLEASE NOTE**

*When chiller is set to "OFF", the display will show either the water temperature or FLD.*

1. Confirm the chiller has reached the desired temperature set on the thermostat. The chiller will continue to run until the set temperature is reached.
2. If the chiller is incorrectly set to **HEA** or **ACH** mode, the unit will not deactivate.
  - See "Setting Operating Mode" on page 29.
3. If the chiller is using an external controller, it may not be set correctly.
  - See "Operating Chiller (With an External Controller)" on page 32.

## Chiller Is Running, Not Cooling (Reversing Models)

1. If the chiller is using an external controller, confirm the chiller is programmed properly to allow for cooling. See "Operating Chiller (With an External Controller)" on page 32.
2. Confirm the chiller mode is set to **COO** operating mode.
3. Confirm the thermostat is set below the current water temperature.
4. Confirm valves are correctly positioned to cool the correct body of water (either the pool or the spa). If cooling a spa that overflows into a pool, confirm the spa is isolated when being cooled (not flowing into the pool).
5. If an error code is displayed, determine and correct the condition causing the code. See "Fault Codes" on page 40.
6. Confirm chiller is transferring heat out of the water.
  - Measure the temperature of air discharge coming out of chiller's fan. If the air is between 8° to 10° warmer than the outside ambient air, the chiller is moving heat out of the water.
7. Confirm that filter pump has a sufficient run-time. The chiller will not run (or cool the water) without water flow. Chiller equipment will generally be set to run 24 hours a day in commercial applications. See "Cooling Recommendations" on page 38.

## Water Coming From Chiller

The water may be normal condensation produced as a by-product of the chiller's refrigeration process. The chiller can produce 8 to 10 gallons of condensation per day depending on the humidity of the ambient air. Determine if the water is condensation or a possible leak.

1. Deactivate chiller, leaving the filter pump on. After several hours, determine if water is still coming from the chiller.
2. If using chlorine or bromine as a pool / spa sanitizer, test the water around the chiller using a test strip. If the test strip indicates that chlorine or bromine is present, a leak may exist.

### **PLEASE NOTE -**

*If desired, a kit is available to re-direct condensation water away from the chiller. See "Condensation Drain Kit (# STK0202)" on page 38.*

## Ice Forming on the Chiller

### **Why ice and frost appear:**

1. When the heat pump operates, air is pulled into the unit and across the cold air coil.
2. As heat is removed from the air, moisture in the air will condense on the surface of the air coil (condensation).
3. Depending on the humidity level, when air temperatures are below 50°F this condensate can begin to freeze. Forming frost then ice.

### **What to expect:**

- The heating of the pool or spa water continues while frost and ice develop.
- The chiller is designed to periodically enter a “defrost” stage to remove the accumulated frost and ice.
- During the “defrost” stage, pool or spa heating is suspended till the end of the “defrost” cycle.

### **Troubleshooting:**

1. The chiller can be more efficient if used during warmer parts of the day. This heat gain can be retained during the colder parts of the day by using a pool blanket.
2. If the chiller forms sheets of ice that never go away during a cold season, conditions may not allow for proper heat transfer. And the chiller should be turned off.
3. If the ambient air temperature is warm and ice is appearing on the chiller, turn off the chiller. Service may be required.